

# BIN BYPASS

## Installation guide

### INSTALL METHODS

VERTICAL METAL UNITS  
VERTICAL RECYCLED  
PLASTIC UNITS  
HORIZONTAL METAL UNITS  
“THE DOUBLER” BRACKET



INSTALL ONTO 120LTR RECTANGULAR BIN ENCLOSURE

1. Remove bin and clear enclosure



2. Mark hole locations on the sheet metal with a pen and then a hole punch.



## INSTALL ONTO 120LTR RECTANGULAR BIN ENCLOSURE

3. Drill holes using an 8mm drill bit



4. Using m8 sized stainless steel bolts of appropriate length attach Bin Bypass to surface



INSTALL ONTO 120LTR RECTANGULAR BIN ENCLOSURE

5. Apply low strength thread locker (3222)



6. Attach nut and tension

