

BIN BYPASS

Installation guide

INSTALL METHODS

VERTICAL METAL UNITS
VERTICAL PLASTIC
UNITS
HORIZTINAL METAL
UNITS
“THE DOUBLER”



INSTALL ONTO 120LTR BIN ENCLOSURE



1. Remove bin and clear enclosure

2. Mark and centre Punch the sheet metal to guide drill



INSTALL ONTO 120LTR BIN ENCLOSURE

3. Drill punch marks using an 8mm drill



4. Using m8 SS bolts of appropriate length attach Bin Bypass to surface



INSTALL ONTO 120LTR BIN ENCLOSURE

5. Apply low strength thread locker (3222)



6. Attach nut and tension

